

TECHNICAL MEMORANDUM  
GEMITE PRODUCTS INC.  
05-05  
Issued 5 May 2005

---

## **Cold Weather Application of Portland Cement based Materials**

During applications of any Portland cement based products in temperatures below 4°C it is important to protect the materials from freezing.

Use plastic tarps to completely enclose the area of work, and use electrical heater(s) to keep the environment above 4-5°C.

The materials must not freeze the first night - but keep them warm for at least 2 days (even better 3 days), while wet curing (e.g. Cem-Kote CW Plus), or air drying (e.g. Cem-Kote Flex ST).

**NOTE: Do not use gas or oil heaters, you may get severe carbonation and carbonation cracking!**

### **Gemite Group of Companies**

*E-mail: [techinfo@gemite.com](mailto:techinfo@gemite.com)*

**Toll Free: 1-888-4-GEMITE (888-443-6483)**

<b>USA:</b>	160-3840 E. Robinson Rd., Amherst NY 14228	Phone: 888-443-6483	Fax: 8884436329
<b>CANADA:</b>	1787 Drew Road, Mississauga ON L5S 1J5	Phone: 905-672-2020	Fax: 9056726780

**Associated Companies Worldwide**